



INSPECTION, CLEANING AND DISINFECTING CONTINUED

REMOVING THE CAPE




First remove the cape cover band to reveal the eight snaps. The cape can then easily be removed by undoing the snaps.

INSPECTING THE HELMET



Having removed the cape, wipe out the inside of the helmet with a soft cloth and mild detergent or a disinfectant wipe. Check the inside for cracks in the shell, damage to the air inlet and head harness.

INNER LENS AND GASKET



Make sure the inner lens gasket seal is securely fitted in the helmet with no cracks or tears in the seal. Check that the inner lens is correctly fitted into the gasket.

When necessary replace lenses as in Figures 3.1 and 3.2.